




CABINET PARTS

REFRIGERATOR


For Models: ED27DSXDW00, ED27DSXDN00, ED27DSXDB00
(White) (Almond) (Black)



2	2174748	Front Roller (2)
3	489456	Screw
4	981122	Roller (Rear) (2)
5	489427	Screw
6	2155013	Clip, Grille
7	489242	Screw
8	2176796	Insert, Air Baffle
9	2156056	Shim
12	2171865	Hinge Top (2)
13	2171868	Shim, Hinge Top
14	489284	Screw
15		Hinge Cover
	1129262	White
	2150343	Almond
	2151694	Black
16	2171851	Hinge Bottom (2)
21		Filler, Wrapper
	1110708	White
	1110709	Almond
	1127272	Black
22		Grille
	2155486	White
	2155487	Almond
	2155485	Black
23	489367	Screw
35	489337	Screw
41	940139	Drain Fitting
42	2172932	Extension Tube
43	1108439	Clip, Drain Tube
44	2172957	Flapper, Drain Extension
47	2176140	Cover, Unit
48		Cabinet (Not A Serviceable Part)
49		Hinge Cover
	1119787	White
	1119789	Almond
	2155938	Black
52	549193	Clamp, Service Cord
53	489084	Screw
54	2155311	Door Closer, Lower Cam (2)
55	489420	Screw

REFRIGERATOR LINER PARTS


For Models: ED27DSXDW00, ED27DSXDN00, ED27DSXDB00
(White) (Almond) (Black)



1		Liner (Not A Serviceable Part)
2	2182762	Escutcheon, Meat Pan Control
3	2182757	Slide, Meat Pan Control
4	658944	Stud
5	2171846	Release Valve
6	487559	Screw
8	1110718	Stud
9	2171996	Ladder, Shelf
10	487539	Screw (4)
11	489290	Screw (2)
16	2179374	Wine Rack
22	1123919	Bracket Retainer
24	2176173	Air Diffuser Assembly
25	2152019	Air Diffuser Cover
26	2150331	Cover, Conduit
27	486298	Screw
29	2162085	Socket
31	2155290	Reservoir
33	527949	Light Bulb
34	2174436	Light Lens
37	488280	Screw (2)


REFRIGERATOR SHELF PARTS

For Models: ED27DSXDW00, ED27DSXDN00, ED27DSXDB00
(White) (Almond) (Black)



1	2174041	Shelf Assembly, Glass Sliding (2)
2	2179283	Snack Bin
3	2179272	Cover, Crisper
4	2174442	Gasket, Cover (Front)
5	2174483	Gasket, Cover (Rear)
6	2179259	Glass, Meat Cover
7	2174149	Glass, Crisper Cover
8	2179267	Cover, Meat Pan
9	2174042	Frame, Shelf (2)
10	2179281	Crisper Pan
11	2179343	Front, Crisper Pan
12	2179342	Slide, Humidity Control
13	2179237	Trim, Handle
14	2179282	Meat Pan
15	2169933	Egg Bin
16	2164373	Egg Carrier
17	2169935	Cover
18	2179350	Deflector
19	2179234	Trim, Handle
20	2172943	Shelf Stud
21	1110718	Shelf Stud
22	2174045	Shelf, Snack Bin
23	2174392	Shelf, Slide (Side To Side)
24	2179243	Trim, Handle
25	2169608	Hook, Shelf
26	489419	Screw
27	2174422	Track, Shelf


FREEZER LINER PARTS
 For Models: ED27DSXDW00, ED27DSXDN00, ED27DSXDB00
 (White) (Almond) (Black)



1		Liner (Not A Seviceable Part)
2	1115380	Slide, Ice Door
3	2174343	Door, Ice Compartment
4	2176134	Grommet
5	489242	Screw
6	842534	Clip, Air Duct (2)
7	1115317	Support, Stud (4)
8	1106982	Stud Rear
9	2171770	Trim, Basket
10	2181765	Basket, Tall
11	2181764	Basket, Slope
12	2181763	Basket
13	946355	Stud, Support
14	2155572	Wiring Cover
15	489176	Screw
17		Slide, Basket
	2181760	Right Side (2)
	2181759	Left Side (2)
18	487042	Screw
19	1115373	Switch, Rocker Arm
20	1110718	Stud (4)
21	1115386	Stud, Shelf (4)
22	2179256	Door, Top Compartment
23	2171714	Shelf, Top Compartment
24	2171705	Light Lens
25	527949	Light Bulb
26	2162085	Light Socket
27	946356	Stud, Front R.S.
	1106982	Stud, Rear R.S.
28		Slide, Container
	1119237	Left Side
	1119293	Right Side
29	489100	Screw
31	2174267	Shelf

MOTOR AND ICE CONTAINER PARTS


For Models: ED27DSXDW00, ED27DSXDN00, ED27DSXDB00
(White) (Almond) (Black)



1	1118386	Bracket, Motor
2	2155263	Motor, Dispenser
3	2152713	Soleniod Assembly
4	2149100	Guide, Solenoid
6	1115374	Clip, Wiring
7	2169490	Wiring Assembly, Ice Dispenser
8	489399	Screw
9	983663	Coupling, Motor
10	489242	Screw
11	2162085	Socket, Light
12	1115339	Cover, Motor
14	2152702	Ice Container
15	983668	Coupling, Conveyor
16	1118480	Stop, Cone
17	1119074	Feeder Cone
18	1119005	Spacer, Step (3)
19	1119007	Spacer, Flat (2)
20	1119006	Blade, Rotary
21	1119012	Blade, Rotary
22	1119013	Blade, Rotary
23	489235	Washer, Plain
24	1119009	Blade, Fixed (2)
25	2157405	Block, Blade
26	489229	Roll Pin
27	1119003	Conveyor
28	2171681	Drum
29	1118470	Drive Bar
30	2171682	Floating Baffle
31	1119018	Nut, Bearing
32	2155231	Control Arm
33	1119020	Spring, Return
34	1119021	Retainer Clip, Rod
35	488886	Screw
37	2157407	Housing, Crusher
38	1119017	Deflector, Ice
39	489234	Washer, Plain
40	489236	Retainer Ring
41	2152021	Sleeve, Auger
42	2152700	Housing Filler
44	2171708	Front Cover, Ice Container
45	527949	Light Bulb
46	2171706	Light Lens, Dispenser

REFRIGERATOR DOOR PARTS


For Models: ED27DSXDW00, ED27DSXDN00, ED27DSXDB00
(White) (Almond) (Black)



1		Refrigerator Door (Includes Item #8)
	2177112	White
	2171597	Almond
	2170605	Black
2	2173643	Retainer, Bottle
3	2177105	Door, Compartment
5	489463	Screw
6	2179582	Shelf Bin (4)
7		Extension, Bottom
	2174282	White
	2174283	Almond
	2174284	Black
8		Door Gasket, Magnetic (Service)
	2159075	Mist Beige
	2159083	Black
9		Handle, Center
	2179366	White
	2179367	Almond
	2179368	Black
11	2179399	Shim
12	2171284	Divider, Bin
13		Extension, Top
	2174279	White
	2174280	Almond
	2174281	Black
14	2155312	Door Closer, Upper Cam
15	489420	Screw
16		Bracket, Door Stop
	2155331	Chrome
	2155329	Black
20	489084	Screw
21		Cover, End Cap
	2174006	White
	2174007	Almond
	2174008	Black


FREEZER DOOR PARTS

For Models: ED27DSXDW00, ED27DSXDN00, ED27DSXDB00
(White) (Almond) (Black)



1		Freezer Door (Includes Item #8 And Dispenser Front Parts)
	2179934	White
	2179935	Almond
	2179936	Black
2		Handle, Center
	2179366	White
	2179367	Almond
	2179368	Black
4	489463	Screw
5	2179399	Shim, End Cap (2)
6	1123293	Divider
7	2179580	Shelf Bin (4)
8		Door Gasket, Magnetic (Service)
	2159074	Mist Beige
	2159082	Black
9	2177845	Trim, Door Shelf
10	489422	Screw
11	2156145	Chute, Ice
12	2155312	Door Closer, Upper Cam
13	489420	Screw
14		Bracket, Door Stop
	2155331	Chrome
	2155329	Black
15	2156006	Plug, Trim
17		Extension, Bottom
	2174282	White
	2174283	Almond
	2174284	Black
18		Extension, Top
	2174279	White
	2174280	Almond
	2174281	Black
21	489084	Screw
22		Cover, End Cap
	2174006	White
	2174007	Almond
	2174008	Black

DISPENSER FRONT PARTS
For Models: ED27DSXDW00, ED27DSXDN00, ED27DSXDB00
(White) (Almond) (Black)



4		Housing Dispenser (Not A Servicable Item)
5	488687	Screw
7		Frame, Slides
	2152717	White
	2152718	Almond
	2152716	Black
8		Slide, Cube/Crush Switch
	2152720	White
	2152721	Almond
	2152719	Black
9	2179993	Door, Ice
10	2157650	Door Mechanism Assembly (Includes Item 9)
12	1120581	Mechanism Delay
13		Grille, Overflow
	1126120	White
	1126121	Almond
	2152678	Black
14	987917	Clip, Bearing (2)
15	983697	Bearing, Lever (3)
16	983696	Spring, Lever (2)
17	2147165	Shield, Wiring
18	488500	Screw
19	625834	Spacer, Switch
22	2157744	Water Fitting Assembly
24		Lever Assembly, Ice Dispenser
	2177144	White
	2177145	Almond
	2177143	Black
25		Guide, Ice
	1124730	White
	1126026	Almond
	1119035	Black
26	488892	Screw
27		Slide, Light Switch
	2152726	White
	2152727	Almond
	2152724	Black
29	2147131	Lamp Holder
31	488361	Screw
32	2147164	Insulator, Control Bracket
33	2147163	Bracket, Control
34	851389	Bulb, Light
35	489101	Screw
36	489155	Screw
38		Lever Assembly, Water Dispenser
	2177149	White
	2177150	Almond
	2177148	Black
39		Plaque, Front Cover
	2174331	White
	2179206	Almond
	2179207	Black
40		Front Cover, Housing (Includes Item 39)
	2174310	White
	2179202	Almond
	2179203	Black
41	2147172	Heat Shield, Frame

45	489000	Screw
46	2162361	Switch, Micro (4)

For Models: ED27DSXDW00, ED27DSXDN00, ED27DSXDB00
(White) (Almond) (Black)



1	486692	Speed Nut
2	1108179	Fan, Blade
3	2164504	Condenser Assembly
4	489337	Screw
5	2155658	Clip, Wire
6	489099	Screw
7	934011	Clip, Tube (3)
8	2161302	Sleeve
9	2158826	Dampener
12	2162358	Cover
13	2162218	Overload (Includes Relay)
15		Relay (See Overload)
17	2169137	Capacitor
19	509812	Screw Grommet
21	489242	Screw
22	2164519	Evaporator
23	2161324	Clamp
24	2169135	Fan, Motor
25	1110674	Tray, Evaporator
26	2149294	Heat Shield
27	2164409	Drier
28	2169446	Compressor (Includes Items 12, 13, 15, 17, 27 & 38) (Also
		Order)
	876765	Tube Kit
29	488687	Screw
30	2157396	Unit Mounting Frame
31	2181709	Unit, Harness
32	548695	Fan, Motor Bracket
33	2176065	Heater, Defrost
34	2161330	Clip
35	2176066	Bi-Metal, Defrost
37	489373	Screw
38	2172890	Wire, Connector
39	1100826	Grommet (4)
40	489340	Screw
41	2149128	Air Baffle
42	2155547	Clip, Heat Shield
43	2161363	Unit Cover, Bottom
44	489396	Clip
48	1127906	Unit Mounting Rail
49	488624	Screw
50	1110663	Guard, Fan
52	851095	Strap
53	489427	Screw
54	227991	Wire Connector
55	488649	Screw
59	983659	Spring-Tube
63	2150347	Union


Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE 6.0 oz. (R-134A)

AIR FLOW PARTS


For Models: ED27DSXDW00, ED27DSXDN00, ED27DSXDB00
(White) (Almond) (Black)



1	2155594	Fan Scroll
2	2155590	Retainer, Fan Motor
3	2161231	Air Scoop
4	489176	Screw
5	2176072	Air Duct Freezer
7	2162404	Fan Motor
8	2169142	Fan Blade
10	2176759	Fan Grommet (2)
11	1115381	Duct, Icemaker
12	2161478	Harness, Fan Evaporator, And Heater, Bi-Metal
13	2155789	Gasket Cover
14	2172840	Wire Tie
16	2155782	Gasket
17	2155612	Cover, Evaporator
18	489355	Screw
21	489242	Screw
22	2161484	Support, R.S
23	2155766	Support, L.S

CONTROL PARTS


For Models: ED27DSXDW00, ED27DSXDN00, ED27DSXDB00
(White) (Almond) (Black)



1	2169148	Control Box
2	1110629	Mounting Bracket
3	489397	Screw (2)
4	2149705	Light Switch
6	2169267	Adaptive Defrost Control
7	489398	Screw (2)
8	940014	Hole Plug
9	2161284	Thermostat Assembly
10	487869	Screw
11	2161250	Cam Assembly
12	1110560	Bearing Body
13	489242	Screw
14	938439	Retainer, Damper
15	1110559	Pivot Arm
16	627068	Screw
17	2162085	Light Socket
18	1115241	Thermostat, Barrier
19	527949	Light Bulb
20	2162460	Control Box Harness
21	1115374	Clip, Wiring
22	1115375	Clip, Wiring
23	1123960	Connecting Rod
24	489285	Fastener, Push-On
25	2179361	Escutcheon, Control Box
26	1116852	Thermostat knob
27	1116853	Knob, Air Control
28	837444	Retainer, Knob
29	489203	Spring Washer

ICEMAKER PARTS

For Models: ED27DSXDW00, ED27DSXDN00, ED27DSXDB00
(White) (Almond) (Black)



1	489084	Screw
2	836489	Fitting, Water Tube
3	488878	Clamp, Tube
4	841707	Insert, Tube
5	628379	Clip, Fuse
7	2155294	Tube, Water
8	1106508	Seal, Gasket
9	489242	Screw
10	2181730	Valve, Solenoid
11	627018	Nut, Compression
13	2171943	Tube, Water Inlet
14	489385	Tube Clamp
18	2174155	Cover
19	488649	Screw
20	628228	Mold & Heater Assembly (Also Order)
	542638	Silicone Grease
22	628356	Cup, Water Fill
23	627843	Ejector
24	627788	Ice Striper
25	627790	Support
26	627796	Retainer, Thermostat
27	628397	Thermostat (Also Order)
	542369	Cement Alumilastic
28	489322	Screw
29	628399	Motor Module
30	489276	Screw
31	2171593	Shut Off Arm
32	628256	Harness, Wiring
33	628320	Bracket
35	628366	Module Assembly (Includes Items 29, 37 & 38)
36	488208	Screw
37	628398	Motor
38	489136	Screw
40	1129179	Nut, Compression
42	488886	Screw
100	4317943	Complete Icemaker Assembly

Parts Not Illustrated and Optional Parts (Not Included)

Customer Touch-Up Material

350942	*Primer, White (13 Oz. Spray Can)
350939	*Enamel, Black (13 Oz. Spray Can)
350930	*Enamel, White (13 Oz. Spray Can)
350956	*Enamel, Almond (13 Oz. Spray Can)
72017	Brush Touch-Up Kit (White)
72107	Brush Touch-Up Kit (Almond)
72032	Brush Touch-Up Kit (Black)

*CAUTION: The spray paint is not to be used where the paint may make contact with the door gaskets.

Miscellaneous

212643	Sealer, Gum (4 Feet)
479502	Tape, Vinyl (3/4 x 108")
876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")
876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")
978941	Insulation, Fiberglass (63-1/2" x 35-1/2" X 2-5/8)

876029	Kit, Foam Slab (30" x 32-1/2" x 1-1/2")
505587	Sealer, Mastic (1 Qt.)
503695	Cork, Sealer (1/4 Pound)
511873	Touch-Up, White Porcelain (2 Oz.)
542638	Grease, Silicone (1/2 Oz.)
542639	Cement, Alumilastic (1-1/4 Oz.)
606755	Bag, Insulation (36-5/8" x 46")
799833	Kit, Evaporator Repair (Aluminum Epoxy)
833938	Kit, Terminal Connector Refinishing Material
799340	Enamel, Black (1 Qt. Uncut)
799344	Enamel, White (1 Qt. Uncut)
978883	Enamel, Almond (1 Qt. Uncut)

LITERATURE PARTS

LIT2180534	Use & Care Guide
LIT2176077	Service & Wiring Sheet
LIT2182526	Energy Label
LIT628370	Modular Icemaker Service Sheet

TORX SCREW WRENCH

1117510	Torx Key
2149072	Ice Crusher Assembly